

Application Instructions for Skylight Roofing Underlayment



SURFACE PREPARATION

For a new roof: Clear any dust, dirt or protrusions from the roof deck.

For an existing roof: Remove all shingles minimum 8" around rough opening except at bottom (this distance will vary depending on skylight location), roofing felt and nails from deck area. The Skylight Roofing Underlayment must not be applied on top of roofing felt. Sweep thoroughly to remove any dust or dirt.



TEMPERATURE

Install Skylight Roofing Underlayment in fair weather when air, roof deck and membrane are at temperatures of 10°C or above. A primer is recommended when temperatures are below 10°C.

STORAGE

Store in a cool dry place, prolonged storage in areas above 32°C should be avoided.

UNDERLAYMENT APPLICATION FOR CURB MOUNT & WOOD DECK MOUNT SKYLIGHTS.

With shingles removed,

1. Position wood curb and attach to roof deck
2. Prior to installation of the flashing, install Columbia Skylights Roofing Underlayment up the vertical edge of the curb and a minimum of 6" onto the roof deck. Work from the bottom of the skylight, up the sides and finish at the top, overlapping corners. At base of skylight, ensure the underlayment adheres to roof deck and runs under shingles.
3. Install the flashing as per Columbia flashing kit instructions.

IMPORTANT: THE SILL FLASHING NEEDS TO BE ON TOP OF THE SHINGLES

